

IRON-ON DIRECTIONS

- Set iron dial between Cotton and Linen
- Cover design with Kraft paper or non-stick cover sheet, Although Kraft Paper is recommended, I supply you with Parchment Paper with every order.
- Place on flat, hard surface (ironing board not recommended)
- Press iron with medium/firm pressure (do not slide iron)
- Press each section of design for 10-15 seconds
- If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds